



DOFFING BIOLOGICAL PPE - EBOLA PATIENTS



- 1 Bleach wipe the long cuff KC500 Purple Nitrile Gloves before opening the door to the patient room.
- 2 Step out of room onto the doffing pad with trash receptacle nearby.



- 3 Once on the doffing pad, if you taped the gloves to the gown, remove the tape gently and discard it before removing the gloves.
- 4 Remove the long cuff KC500 Purple Nitrile Gloves using glove-in-glove technique and discard them in the trash.

If the inner standard patient care gloves are accidentally removed during the doffing of the nitrile gloves, additional clean gloves are available on the doffing pad.

